

Internal Tape Backup Unit	107
Installing the Tape Backup Unit	107
Removing the Tape Backup Unit	110
Integrated Storage Controller Card	111
Removing the Integrated Storage Controller Card	112
Installing the Integrated Storage Controller Card	112
RAID Battery	116
Removing a RAID Battery	116
Installing a RAID Battery	117
Cable Routing	118
Removing the Cable Retention Bracket	118
Installing the Cable Retention Bracket	119
Expansion Cards and Expansion-Card Risers	119
Expansion Card Installation Guidelines	119
Installing an Expansion Card	120
Removing an Expansion Card	122
Removing Expansion-Card Riser 1	123
Replacing Expansion-Card Riser 1	124
Removing Expansion-Card Riser 2	125
Replacing Expansion-Card Riser 2	126
Removing Expansion-Card Riser 2 From the Expansion-Card Bracket	127
Replacing the Riser 2 Board on the Expansion-Card Bracket	128
System Memory	129
General Memory Module Installation Guidelines	129
Mode-Specific Guidelines	131
Installing Memory Modules	134